

AURO

Wallpaper Glue No. 389

Use: For the glueing of light, medium-heavy and heavy wallpapers.

Preparation: Substrate must be firm, dry and clean. Fill cracks and holes with AURO Wall Filler No. 329. Crumbling plaster can be solidified with AURO Primer for Various Plaster No. 301. Pre-paste highly absorbent substrates.

Application: Stir powder evenly and clot-free into cold water. Let swell for one hour and stir well again. Paste the rear of the wallpaper evenly, let soak and paste on. Apply glue especially thorough at the seams.

Composition: Methyl cellulose

Processing	Mixing ratio	Water per 200g	200g suffice for approx.:
Pre-pasting	1 : 80	16 Litres	120 – 160 m ²
Light wallpapers	1 : 50	10 Litres	80 – 100 m ²
Medium heavy wallpaper	1 : 45	9 Litres	60 – 80 m ²
Heavy wallpapers, raw fiber papers	1 : 40	8 Litres	40 – 60 m ²

Attention: Store dry and cool and keep out of reach of children. Do not pour into the sewage. Dry remnants can be composted or put into the household garbage. Disposal of liquid residues: EAK waste code 200112; EAK classification: paints, glues.